

USER MANUAL

NANLUX

INNOVATE · ILLUMINATE

Evolve 1200B

DMX REFERENCE GUIDE

WWW.NANLUX.COM

CATALOG

CCT 8bit	01	PULSE	09
CCT 16bit	02	STORM	10
ULTIMATE DMX 8bit - CCT MODE	03	TV	11
ULTIMATE DMX 8bit - EFFECT MODE	04	PAPARAZZI	12
DMX EFFECT CHART		CANDLE/FIRE	13
CCT LOOP	06	BAD BULB	14
INT LOOP	07	FIREWORK	15
FLASH	08	EXPLOSION	16
		WELDING	17

CCT 8bit

CHANNEL	VALUE	%	FUNCTION	NOTES
1	0-255	0-100	DIMMER 0.0% to 100.0%	
2	0-255	0-100	CCT	2700K - 6500K

When "DMX Reduced Channels" is ON, the following channels are reduced in all DMX modes except ULTIMATE DMX MODE.

CHANNEL	VALUE	%	FUNCTION	NOTES
3	0-63 64-127 128-191 192-255	0-25 26-50 51-75 76-100	SMART FULL SPEED HALF SPEED FAN OFF	
4	0 - 3 4 5 6 7-255	0 - 1.2 1.6 2.0 2.4 2.7 - 100	STROBE OFF Random Fast Random Medium Random Slow Variable Strobe(0.4Hz --> 25Hz)	
5 - 6			RESERVED	

CCT 16bit

CHANNEL	VALUE	%	FUNCTION	NOTES
1-2	0-65535	0-100	DIMMER 0.0% to 100.0%	
3-4	0-65535	0-100	CCT	2700K - 6500K

When “DMX Reduced Channels” is ON, the following channels are reduced in all DMX modes except ULTIMATE DMX MODE.

CHANNEL	VALUE	%	FUNCTION	NOTES
5	0-63 64-127 128-191 192-255	0-25 26-50 51-75 76-100	SMART FULL SPEED HALF SPEED FAN OFF	
6	0 - 3 4 5 6 7-255	0 - 1.2 1.6 2.0 2.4 2.7 - 100	STROBE OFF Random Fast Random Medium Random Slow Variable Strobe(0.4Hz --> 25Hz)	
7 - 10			RESERVED	

ULTIMATE DMX 8bit - CCT MODE

CHANNEL	VALUE	%	FUNCTION	NOTES
1	0-255	0-100	DIMMER 0.0% to 100.0%	
2	0-63 64-127 128-255	0-25 26-50 51-100	MODE CCT EFFECT RESERVED	0 ≤ value ≤ 63
3	0-255	0-100	CCT	2700K - 6500K
4-10			N/A	
11	0-63 64-127 128-191 192-255	0-25 26-50 51-75 76-100	SMART FULL SPEED HALF SPEED FAN OFF	

ULTIMATE DMX 8bit - EFFECT MODE

CHANNEL	VALUE	%	FUNCTION	NOTES
1	0-255	0-100	DIMMER 0.0% to 100.0%	
2	0-63 64-127 128-255	0-25 26-50 51-100	MODE CCT EFFECT RESERVED	64 ≤ value ≤ 127
3	0-18 19-36 37-54 55-72 73-90 91-108 109-126 127-144 145-162 163-180 181-198 199-216 217-255	0-7 8-14 15-21 22-28 29-35 36-42 43-50 51-57 58-64 65-71 72-78 79-85 86-100	EFFECT MODE CCT LOOP INT LOOP FLASH PULSE STORM TV PAPARAZZI CANDLE/FIRE BAD BULB FIREWORK EXPLOSION WELDING RESERVED	
4	0-255	0-100	DMX EFFECTS PARAMETER #1	See DMX Effects chart
5	0-255	0-100	DMX EFFECTS PARAMETER #2	See DMX Effects chart
6	0-255	0-100	DMX EFFECTS PARAMETER #3	See DMX Effects chart
7	0-255	0-100	DMX EFFECTS PARAMETER #4	See DMX Effects chart

ULTIMATE DMX 8bit - EFFECT MODE

CHANNEL	VALUE	%	FUNCTION	NOTES
8	0-255	0-100	DMX EFFECTS PARAMETER #5	See DMX Effects chart
9	0-255	0-100	DMX EFFECTS PARAMETER #6	See DMX Effects chart
10	0-255	0-100	DMX EFFECTS PARAMETER #7	See DMX Effects chart
11	0-63 64-127 128-191 192-255	0-25 26-50 51-75 76-100	SMART FULL SPEED HALF SPEED FAN OFF	

DMX EFFECT CHART

EFFECT	CCT LOOP 0 ≤ value ≤ 18			
CH4/PARAMETER #1	CCT HIGH			
CH5/PARAMETER #2	CCT LOW			
CH6/PARAMETER #3	SPEED			
CH7/PARAMETER #4	CYCLE:ONE WAY = 0-85[0%-33%] CYCLE:TWO WAY = 86-170[34%-66%] CYCLE:REVERSE = 171-255[67%-100%]			
CH8/PARAMETER #5	ADD-ON:OFF = 0-63[0%-25%]	ADD-ON:FLASH = 64-127[26%-50%]	ADD-ON:RANDOM FLASH = 128-191[51%-75%]	ADD-ON:PULSE = 192-255[76%-100%]
CH9/PARAMETER #6	N/A	INTERVALS	SPEED	PULSES/MIN
CH10/PARAMETER #7	N/A	FLASH RATIO	N/A	N/A

DMX EFFECT CHART

EFFECT	INT LOOP 19 ≤ value ≤ 36			
CH4/PARAMETER #1	DIM LOW			
CH5/PARAMETER #2	CCT			
CH6/PARAMETER #3	SPEED			
CH7/PARAMETER #4	CYCLE:ONE WAY = 0-85(0%-33%) CYCLE:TWO WAY = 86-170(34%-66%) CYCLE:REVERSE = 171-255(67%-100%)			
CH8/PARAMETER #5	ADD-ON:OFF = 0-63(0%-25%)	ADD-ON:FLASH = 64-127(26%-50%)	ADD-ON:RANDOM FLASH = 128-191(51%-75%)	ADD-ON:PULSE = 192-255(76%-100%)
CH9/PARAMETER #6	N/A	INTERVALS	SPEED	PULSES/MIN
CH10/PARAMETER #7	N/A	PULSES/MIN	N/A	N/A

DMX EFFECT CHART

EFFECT	FLASH 37 ≤ value ≤ 54	
CH4/PARAMETER #1	CCT	
CH5/PARAMETER #2	INTERVALS	
CH6/PARAMETER #3	FLASH RATIO	
CH7/PARAMETER #4	PAUSE: OFF = 0-127(0%-50%)	PAUSE: ON = 128-255(51%-100%)
CH8/PARAMETER #5	N/A	
CH9/PARAMETER #6	N/A	
CH10/PARAMETER #7	N/A	

DMX EFFECT CHART

EFFECT	PULSE 55 ≤ value ≤ 72
CH4/PARAMETER #1	CCT
CH5/PARAMETER #2	PULSES/MIN
CH6/PARAMETER #3	N/A
CH7/PARAMETER #4	N/A
CH8/PARAMETER #5	N/A
CH9/PARAMETER #6	N/A
CH10/PARAMETER #7	N/A

DMX EFFECT CHART

EFFECT	STORM 73 ≤ value ≤ 90		
CH4/PARAMETER #1	CCT		
CH5/PARAMETER #2	FLASH TIMES HIGH		
CH6/PARAMETER #3	FLASH TIMES LOW		
CH7/PARAMETER #4	TRIGGER: AUTO = 0-127(0%-50%)	TRIGGER: MANUAL = 128-255(51%-100%)	
CH8/PARAMETER #5	INTERVAL HIGH	Trigger: OFF = 0-127(0%-50%)	Trigger: ON = 128-255(51%-100%)
CH9/PARAMETER #6	INTERVAL LOW	N/A	
CH10/PARAMETER #7	PAUSE: OFF = 0-127(0%-50%)	PAUSE: ON = 128-255(51%-100%)	N/A

DMX EFFECT CHART

EFFECT	TV 91 ≤ value ≤ 108
CH4/PARAMETER #1	DIM LOW
CH5/PARAMETER #2	CCT
CH6/PARAMETER #3	CCT SHIFT
CH7/PARAMETER #4	SPEED
CH8/PARAMETER #5	N/A
CH9/PARAMETER #6	N/A
CH10/PARAMETER #7	N/A

DMX EFFECT CHART

EFFECT	PAPARAZZI 109 ≤ value ≤ 126
CH4/PARAMETER #1	CCT
CH5/PARAMETER #2	SPEED
CH6/PARAMETER #3	N/A
CH7/PARAMETER #4	N/A
CH8/PARAMETER #5	N/A
CH9/PARAMETER #6	N/A
CH10/PARAMETER #7	N/A

DMX EFFECT CHART

EFFECT	CANDLE/FIRE 127 ≤ value ≤ 144
CH4/PARAMETER #1	DIM LOW
CH5/PARAMETER #2	CCT
CH6/PARAMETER #3	CCT SHIFT
CH7/PARAMETER #4	SPEED
CH8/PARAMETER #5	FLICKER: OFF = 0-127(0%-50%) FLICKER: ON = 128-255(51%-100%)
CH9/PARAMETER #6	N/A
CH10/PARAMETER #7	N/A

DMX EFFECT CHART

EFFECT	BAD BULB 145 ≤ value ≤ 162
CH4/PARAMETER #1	CCT
CH5/PARAMETER #2	INTENSITY
CH6/PARAMETER #3	SPEED
CH7/PARAMETER #4	N/A
CH8/PARAMETER #5	N/A
CH9/PARAMETER #6	N/A
CH10/PARAMETER #7	N/A

DMX EFFECT CHART

EFFECT	FIREWORK 163 ≤ value ≤ 180
CH4/PARAMETER #1	CCT
CH5/PARAMETER #2	CCT SHIFT
CH6/PARAMETER #3	SPEED
CH7/PARAMETER #4	DECAY
CH8/PARAMETER #5	N/A
CH9/PARAMETER #6	N/A
CH10/PARAMETER #7	N/A

DMX 特效数据表

EFFECT	EXPLOSION 181 ≤ value ≤ 198	
CH4/PARAMETER #1	CCT	
CH5/PARAMETER #2	DECAY	
CH6/PARAMETER #3	TRIGGER: AUTO = 0-127(0%-50%)	TRIGGER: MANUAL = 128-255(51%-100%)
CH7/PARAMETER #4	SPEED	Trigger: OFF = 0-127(0%-50%) Trigger: ON = 128-255(51%-100%)
CH8/PARAMETER #5	N/A	
CH9/PARAMETER #6	N/A	
CH10/PARAMETER #7	N/A	

DMX EFFECT CHART

EFFECT	WELDING 199 ≤ value ≤ 216
CH4/PARAMETER #1	DIM LOW
CH5/PARAMETER #2	CCT
CH6/PARAMETER #3	SPEED
CH7/PARAMETER #4	PAUSE: OFF = 0-127[0%-50%] PAUSE: ON = 128-255[51%-100%]
CH8/PARAMETER #5	N/A
CH9/PARAMETER #6	N/A
CH10/PARAMETER #7	N/A

Version: V2 2022-08-30

 +86-754-85751187

 +86-754-85300887

 info@nanlux.com

 Zhanglin,324,Dongli Chenghai Shantou Guangdong China

Guangdong NanGuang Photo&Video Systems Co., Ltd